


Parts Information: 10 Tonne Professional Trolley Jack, Long Reach, Air / Manual Operation Model No: 10001A



Item	Part No.	Description	Qty
1	10001A-01	Handle Assembly	1
2	10001A-02	Pump Assembly	1
3	10001A-03	Handle Socket	1
4	10001A-04	Handle Location Seat	1
5	10001A-05	Connection	1
6	10001A-06	Rear Swivel Castor Assembly	2


Item	Part No.	Description	Qty
7	10001A-07	Front Fixed Wheel	2
8	10001A-08	Return Spring	2
9	10001A-09	Saddle	1
10	10001A-10	Tool Tray	1
11	10001A-11	Air Hose Assembly	1
12	JP31	Safety Rubber Jack Pad	1

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Parts Information: 10 Tonne Professional Trolley Jack, Long Reach, Air / Manual Operation Model No: 10001A



NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK

Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland

Tel: 01284 757500 • Email: sales@sealey.co.uk • Web: www.sealey.co.uk



Parts Information: 10 Tonne Professional Trolley Jack, Long Reach, Air / Manual Operation Model No: 10001A

Item	Part No.	Description	Qty
P01	10001A-P01	Limited Ring	1
P02	10001A-P02	Dust Ring	1
P03	10001A-P03	O-Ring 53 x 4mm	1
P04	10001A-P04	O-Ring 75 x 2.5mm	1
P05	10001A-P05	Limited Ring	1
P06	GSM88.S	Grub screw m8x8 (single)	5
P07	SB-5.5	Steel Ball 5.5mm	7
P08	GSM68.S	Grub screw m6x8 (single)	2
P09	SB-4.0	Steel Ball 4.0mm	1
P10	10001A-P10	Piston Rod	1
P11	10001A-P11	Nylon Retaining Ring	1
P12	10001A-P12	Seal	1
P13	10001A-P13	O-Ring 64 x 5.3mm	1
P14	10001A-P14	Piston Rod	1
P15	10001A-P15	Washer	1
P16	10001A-P16	O-Ring 10.5 x 2mm	1
P17	MSP610.S	Machine Screw Pan Head Phillips M6 X 10mm	4
P18	10001A-P18	Limited Plate	2
P19	SB-7.2	Steel Ball 7.2mm	2
P20	10001A-P20	Spring	1
P21	10001A-P21	O-Ring 35 x 3mm	1
P22	10001A-P22	Pump Housing	1
P23	10001A-P23	O-Ring 7.8 x 2.2mm	3
P24	10001A-P24	Air Vent Screw	1
P25	10001A-P25	Pin	1
P26	10001A-P26	Piston Core (A)	1
P27	SB-6.6	Steel Ball 6.6mm	2
P28	10001A-P28	Spring	1
P29	10001A-P29	Washer	3
P30	10001A-P30	Screw	3
P31	10001A-P31	U-Ring 28 x 35.5 x 5mm	1
P32	10001A-P32	Washer	1
P33	10001A-P33	O-Ring 16 x 3mm	1
P34	10001A-P34	Piston Core (B)	1
P35	10001A-P35	Spring	1
P36	10001A-P36	Steel Ball Seat	1
P37	SB-5.0	Steel Ball 5.0mm	3
P38	10001A-P38	Copper Washer	1
P39	10001A-P39	Valve Seat	1
P40	10001A-P40	Spring	1
P41	10001A-P41	O-Ring 5.5 x 3mm	1

Item	Part No.	Description	Qty
P42	10001A-P42	Release Valve Core	1
P43	10001A-P43	Screw	1
P44	10001A-P44	Copper Washer	2
P45	10001A-P45	Seal	2
P46	10001A-P46	Screw	2
P47	10001A-P47	Steel Ball	2
P48	10001A-P48	Steel Ball Seat	2
P49	10001A-P49	Spring	2
P50	10001A-P50	Screw	4
P51	10001A-P51	Steel Ball Seat	1
P52	10001A-P52	Screw	2
P53	10001A-P53	Red Cap	2
P54	10001A-P54	Steel Ball Ø7.5mm	2
P55	10001A-P55	Spring	1
P56	10001A-P56	Copper Washer	2
P57	10001A-P57	Air Motor	1
P58	SB-6.0	Steel Ball 6.0mm	2
P59	SB-3.0	Steel Ball 3.0mm	1
P60	10001A-P60	Screw	2
P61	10001A-P61	Valve Seat	1
P62	10001A-P62	Nylon Washer	1
P63	10001A-P63	External Circlip Ø65	1
P64	GSM610.S	Grub screw m6x10 (single)	1
P65	SB-8.0	Steel Ball 8.0mm	1
P66	10001A-P66	Copper Washer	1
P67	10001A-P67	Seal	1
P68	10001A-P68	Screw	1
P69	10001A-P69	Nylon Washer	1
P70	10001A-P70	Screw	1
P71	10001A-P71	Steel Ball Plate	1
P72	10001A-P72	Oil Outlet Valve Seat	1
P73	10001A-P73	O-Ring 5.5 x 1.5mm	1
P74	10001A-P74	Washer	1
P75	10001A-P75	Push Rod	1
P76	10001A-P76	O-Ring 3.1 x 1.6mm	1
P77	10001A-P77	Nylon Washer	1
P78	SB-4.7	Steel ball 4.7mm	1
P79	10001A-P79	Spring	1
P80	10001A-P80	Limited Rod	1
P81	10001A-P81	Spring	1
P82	10001A-P82	Lengthen Rod	1

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Jack Sealey Ltd t/a Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk, IP32 7AR UK
Jack Sealey (EU) Ltd t/a Sealey Group, Farney Street, Carrickmacross, Co. Monaghan, A81 PK68 Ireland
Tel: 01284 757500 • **Email:** sales@sealey.co.uk • **Web:** www.sealey.co.uk