



Item	Part No.	Description
1	RWH20-V2-01	Inlet Hose Connector
2	RWH20-V2-02	Front Cover
3	RWH20-V2-03	Cover, Left Side
4	RWH20-V2-04	Housing, Left Side
5	RWH20-V2-05	Hose Guide Screw Sleeve
6	RWH20-V2-06	Top Handle
7	RWH20-V2-07	Wall Bracket Mount
8	RWH20-V2-08	Wall Bracket Mounting Rod
9	RWH20-V2-09	Spring Housing Cover
10	RWH20-V2-10	Housing, Right Side
11	RWH20-V2-11	Panel, Right Side
12	RWH20-V2-12	Centre Shaft

Item	Part No.	Description
13	RWH20-V2-13	Drum Wheel Cover
14	RWH20-V2-14	Drum
15	RWH20-V2-15	Outlet Hose Connector
16	RWH20-V2-16	Drum Wheel Plate
17	RWH20-V2-17	Lock Pin
18	RWH20-V2-18	Hose 20m
19	RWH20-V2-19	Hose Guide Assembly
20	RWH20-V2-20	Main Spring
21	RWH20-V2-21	Guide Belt
22	RWH20-V2-22	Stop Ball Assembly
23	RWH20-V2-23	Spring Tension Cover

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.