




Item	Part No.	Description
1	SG18/01	Body
2	SG18.V2-17	Inlet Fitting
3	SG18/09A	Air Valve
5	SG18.V2-04	Valve Stem
7	SG18/07	Base
8	SG18.V2-03	Gasket
10	SG18.V2-24	Packing
11	SG18.V2-25	Gasket
12	SG18.V2-08	Spring Dia 7.64mm
13	SG18.V2-27	Seat
14	SG18.V2-28	Packing
15	SG18.V2-23	Needle
16	SG18.V2-30	Steel Tube (Outer)
17	SG18.V2-29	Steel Tube (Inner)
18	SG18.V2-31	Front Fitting
19	SB-4.0	Steel Ball 4.0mm

Item	Part No.	Description
20	SG18/20	Spring
21	SG18/21	Seat, Backing
22	SG18.V2-21	Backing Cap
23	SG18.V2-26	Plastic Ring
24	SG18.V2-33	Teflon Packing
25	SG18.V2-22	Needle Base
26	SG18.V2-08	Spring Dia 7.64mm
27	SG18.V2-12	Spring
28	SG18.V2-13	Adjusting Cap
29	SG18/29	Seat, Adjusting
--	SG18.V2-34	Cup (Not Shown)
--	SG18.V2-14	Trigger (Not Shown)
--	SG18.V2-35	Coupler (Not Shown)
--	SG18.V2-B	Hook Probe (Not Shown)
--	SG18.V2-C	360o Probe (Not Shown)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.